



1½" PERIMETER TRIM

INSTALLATION INSTRUCTIONS

Recommended Tools



Measuring Tape



Pencil



Chalk Line



Plumb Bob



Level



Speed Square



Chop Saw



Table Saw



Hammer



Utility Knife




Drill/Impact Driver




Caulking Gun

#6914 Perimeter Trim 1½"



12' 6" Lengths

#6915 Trim Receiver



Common Applications

1½" Perimeter Trim is typically used for inside corners, soffit/eave terminations, and transitions.



Before Installation

- Check local building codes before installation.
- Read all instructions for both Everlast siding and compatible trim products.
- Use of pocketed trim is required and must have a minimum pocket width of $\frac{3}{4}$ " (projection from the wall). Pocket depth minimum $\frac{5}{8}$ " for course runs less than 24'. Over 24', plan pocket depth $\frac{3}{4}$ " or greater. The trim must be installed prior to installing Everlast siding.
- Do not install Everlast siding in temperatures below 0°F
- Inspect trim for any breakage, foreign objects, surface defects, color consistency, and correctness.
- Use a fine tooth or plywood blade with a 60 tooth count minimum to cut all material.
- Fasten material using an exterior grade nail or screw. (Recommended: galvanized/stainless/non-corrosive roofing nail or screw).
- Fasten trim through every other or every third nail hole, while checking for an aesthetic installed presentation. Do not over drive the fasteners. Fastening tightly may distort the trim.
- To keep miter and butt joint ends tightly joined, use a PVC glue or plastic weld to bond together.
- Use a glue accelerator to speed cure time.

Job Site Storage

- Do not stack trim more than three skids high.
- Do not store bundles in a vertical position.
- Store trim inside when possible.
- Avoid storing trim in direct sunlight. Cover trim prior to installation with a tarp and/or supplied shroud.
- Keep trim away from heat sources.
- If storing trim outside, use wood (or equivalent) supports to avoid direct contact with the ground.
- As a premium product, handle Everlast trim as you would fine grade lumber.
- Lift trim from the middle of the product length.
- Never slide or drag objects across the reveal surface.
- Use caution to not scratch trim surface when opening bundle packaging with a knife or sharp object.



Preparing Walls

- Everlast trim must be installed over flat and level exterior walls with 16" or 24" on-center framing.
- Everlast siding serves as a rain screen, not a weather-resistant barrier. The siding must be installed over a weather-resistant barrier.

- Properly flash around all windows, doors, rake boards, chimneys, and areas of transition between dissimilar materials.
- If installing over concrete block, poured concrete, or brick, siding must be installed over 1"x3" furring strips.
- If exterior walls are not flat or level, a quality underlayment should be installed first to create a flat and level surface.

Installing at Roofline



- When installing siding and trim along rooflines, always provide 1" minimum space between the roof and first course of siding.
- In geographies with extreme temperatures and/or along metal roofs, leave a minimum of 3" space.




Inside Corners



- Measure the height of the inside corner wall.
- Cut two trim receivers using a power saw with a fine tooth or plywood blade with a 60 tooth count minimum.
- To achieve a uniform inside corner, install a 1"x1" weather-treated block along the height of the wall (Figure 1a/b).



- Place the trim receiver against the weather-treated block and wall.
- Fasten every 8" to 12" along the nail hem making sure the receiver is securely fastened using galvanized, stainless, or corrosion-resistant nails or screws (Figure 2).




- Install Everlast Lap Siding or Board & Batten per the siding installation instructions (Figure 3).



- Measure and cut the perimeter trim and snap into the receiver (Figure 4a/b).

Top view



- For additional details, please visit everlastsiding.com/quick-guide-installation-videos



Soffit/Eave Terminations and Transitions



- Before the last piece of Everlast siding is installed, measure the length of the termination or transition area.
- Cut the trim receiver using a power saw with a fine tooth or plywood blade with a 60 tooth count minimum.
- In situations where the termination or transition exceeds 12', the conjoining trim receivers can be straight miter cut and butted together.
- Fasten the trim receiver to the wall approximately every 8" to 12" along the nail hem making sure the receiver is securely fastened using galvanized, stainless, or corrosion-resistant nails or screws (Figure 5).




Figure 5

- Install the last piece/course of siding per the installation instructions. Use required seam brackets on courses exceeding 12'. No face nailing is required; panel fasteners will set at the top of the panel (Figure 6).



Figure 6

- Measure and cut the Perimeter Trim and snap into the receiver (Figure 7a/b).

Top view




Figure 7a



Front view

Figure 7b

- For additional detail, please visit everlastsiding.com/quick-guide-installation-videos

Everlast® Call Center Support Line

8am–5pm EST Mon–Fri
Toll Free (844) 494-7920

www.EverlastSiding.com

©2025 Chelsea Building Products, Inc.


EVERLAST®
Advanced Composite Siding

 **CHELSEA®**
BUILDING PRODUCTS
a member of aluplast group

Everlast® is a registered trademark of Chelsea Building Products, Inc.

#CBPEV-12-25-TRIM